

# MIS ASSOCIATES INC

## T-Jet – Smooth Heat Transfer Paper



**T-Jet - Heat Transfer Paper – our** T-Jet paper comes in two sizes and works great with both heat presses and iron transfer processes. We have produced a number of transfers with our new Clam Press and the results are simply amazing. With our Perpetual Archival ink this paper transfers images of all sorts with spectacular clarity. We stock two sizes of this paper in various quantities for your convenience.

**MIS-TJET-8511-10**  
**MIS-TJET-8511-50**  
**MIS-TJET-8511**

**8.5x11 10 sheet count**  
**8.5x11 50 sheet count**  
**8.5x11 100 sheet count**

**MIS-TJET-1117**  
**MIS-TJET-1117-50**

**11x17 100 sheet count**  
**11x17 50 sheet count**

**MIS ASSOCIATES INC**

**1070 West Silver Bell Rd.**

**LAKE ORION, MI 48362**

---

**Phn: 248-391-2163**

**[www.inksupply.com](http://www.inksupply.com)**

**Fax: 248-391-2527**

# Usage instructions for T-Jet Heat Transfer Paper

## TIPS FOR BEST RESULTS

1. For best results, use an Epson printer with MIS Perpetual Archival inks. Not recommended for application on dark color fabrics, for best results use with 100% cotton or poly/cotton fabrics.
2. Images appear best when dark color images are applied to light fabric shirts.
3. It is best to wash the garment before applying the transfer images.
4. This paper is not for use in laser printers or color laser copiers. Experiment with different settings for your image.

**DO NOT USE AN HP DESKJET 1200C OR 1600C PRINTER.**

5. Allow the printed image to dry for approximately 15 minutes before transferring.

## COMMERCIAL HEAT PRESS

1. When using dye-based inks make sure you let the image dry for 15 – 20 to avoid any damage to the print.
2. When using pigment archival inks, you need only allow a few minutes for the ink to dry before transferring onto the shirt or other transfer items.
3. For improved results, cut the image out from the transfer paper.
4. Set the heat press at 325 - 360 Fahrenheit. Experiment for the best heat level on your substrate.
5. Use low to medium pressure when applying the heat press.
6. Press for 5 - 8 seconds only. This may also require some adjustments to achieve your best results.
7. Peel transfer paper from the fabric immediately after transferring the image for best results. Do not peel cold.

## HOME IRONING

1. It is best to do the ironing on a smooth, hard, non-porous surface. Fold a pillowcase in half and place it on top of the ironing surface. Make sure the ironing area is smooth and free from wrinkles.
2. After the transfer is dry, trim around the image
3. Set the iron to the hottest setting (cotton or linen)
4. Do not add water to the iron and make sure the steam setting is turned off.
5. Allow the iron to preheat for 5 minutes.
6. Fold a pillowcase in half or double fold the t-shirt so that the area you intend to decorate is facing upward. Make sure all wrinkles are out.
7. Iron the entire paper for 10 seconds to tack your image down.
8. Then place the iron in one corner, Press down firmly while slightly moving the iron back and forth along the edge of the paper for at least 30 seconds.
9. Peel hot.

## WASHING INSTRUCTIONS

1. Wash in cold water with mild detergent and no bleach
2. Turn the shirt inside out before washing
3. Remove the washed garment immediately from the spin cycle of the washer. Do not leave in washer for any extended period.
4. Tumble dry the garment using low heat.
5. Use MIS Perpetual Archival pigment inks for the best washability