

HP Color Cartridge Primer for HP 51641, C1823A, and C6578D



Purpose:

The MIS HP Cartridge Primer is used to prime HP color cartridges after refilling with ink. Foamy ink right at the bottom of the sponge can prevent the cartridges from working, even though they have plenty of ink in them.

How to Use:

Complete all refilling activity before using the Primer.

Insert the cartridge into the black plastic housing so that the print head presses against the piece of rubber on the inside. Snap the cartridge in place so it is tight.

Attach an empty 10 cc syringe to the fitting on the end of the Primer.

Pull back on the syringe plunger and draw out 1.5 cc of ink. If equal amounts of ink come from each of the 3 color chambers you will have a mixture of cyan, magenta, yellow. One half of a cc of each color.

This should remove enough of the foamy ink to get the cartridge started.

Disconnect the syringe. Wash out the Primer housing and syringe with warm water and put it away for use another day.